

CHE381 LAB -6

Distillation Column: Steady State & Dynamics

Name – Vivek Yadav (211181)


date – 08-03-24

Aim - to recover 99.5% of benzene at top.

Base method – PENG-ROB.

Equipments used : RadFrac Column , Pumps , Valves.

1)



Diameter of column = 1.019124658 m , also $L=2D$ and time =10 min

On calculating we get

Diameter of reflux drum = 1.058 m and length =2.116 m

for sump diameter = 1.348 m and length = 2.696 m


Column Diameter (m)	1.019124658
Total Trays (Nt)	36
Feed stage	18
Sensitivity tray	28


flow rates :

mole fractions :


Material	Feed(kmol/hr)	Dist(kmol/hr)	Bot(kmol/hr)	Material	Feed	Dist	Bot
Benzene	50	49.75	0.25	Benzene	0.5	0.995	0.05
toluene	50	0.25	49.75	toluene	0.5	0.05	0.995

2) Graphs :






3) Column diagram with controller :




4) Tuning Parameters :

Parameters	Gain	Integral Time	Derivative Time
Pc	51.1	4	0
Tc	29.95	3.5	0


5) i) Transient response for +5% composition




Toluene Composition in Bottom



Benzene flow rate




Toluene Flow rate




ii) Transient response for -5% composition


Temperature VS Time




Benzene Composition in Distillate




Benzene Flow Rate



Toluene Composition in Bottom




Toluene Flow Rate




iii) Transient response for +10% flow rate


Temperature VS Time




Benzene Composition in Distillate



Benzene Flow Rate



Toluene Composition in Bottoms



Toluene Flow Rate

